

SAFE OPERATING PROCEDURE

Alternating Test Bench LOCATION: Automotive Workshop

PERSONAL PROTECTIVE EQUIPMENT



Version: 2	Key Contact: George Fisher
Effective Date: 18/09/2020	Speciality/Position: Technician
Review Date: December 2022	Contact number: 021 190 4236
Permits required	Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS Remove as necessary	List	Control Method	Lock out Yes or No
Electric shock	Electricity	Test and tag all leads, visual check of all leads and power switches to ensure no damage	
Falling objects	Secure alternator/Starter	Tighten clamp and check	
Moving Machinery	Be aware of drive belt	Adjust drive belt	
Loose wiring	all wiring must be away from pulleys/belts	Use good clips	

PURPOSE/PROCESS

To test automotive alternator function

PROCEDURES:

DO NOT use this machine unless you have proven to your trainer that you are competent

Pre Start Check

1. Check the surrounding area is free from clutter to prevent slips, trips and falls.
2. Check power leads for damage, wear and tear.
3. Ensure that guards are secure and correctly fitted before starting.
4. Ensure the alternators and starters are secure at all times
5. Check drive belts have been tensioned correctly.
6. Make sure any loose items are well clear of drive belts.

7. Know where the isolation switch is to turn the machine off in an emergency



Operation

1. Fit alternator and wire up with dash light and meters.
2. Make shore that the belt area is clear.
3. Plug machine in.
4. Start drive motor to drive alternator and then live in field current.
5. Alternator light will go out if charging.
6. Take all your readings and complete your test.

Close Down

1. To stop turn drive motor off and light will come back on.
2. Unplug before disconnecting or adjusting.
3. Clean down the machine after use.
4. Report any defects, noises, to your tutor.

Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Technician		
Reviewed by	Marie Dennis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan			

Document Control

Date	Revision number	Modifications	Revised by	Approved by
10.03.20	1	New format	George Fisher	Marie Dennis