

SAFE OPERATING PROCEDURE

Rolling Brake Tester LOCATION:

TOI-OHOMAI
Institute of Technology

PERSONAL PROTECTIVE EQUIPMENT



Version: 2	Key Contact: George Fisher
Effective Date: 18/09/2020	Speciality/Position: Technician
Review Date: September 2022	Contact number: 021 190 4236
Permits required	Confined space ☐ Hot Works ☐ Working at Heights ☐

HAZARDS ASSOCIATED WITH THIS EQUIPMENT

PERMANENT HAZARDS <i>Remove as necessary</i>	List	Control Method	Lock out Yes or No
Moving vehicles	Vehicles have to be driven onto brake tester	<i>Do not leave vehicle unattended when performing brake test, ensure all persons are in a safe place when performing the brake test.</i>	
Moving Machinery	Rollers can start at any time and cause en Do not accelerate the vehicle when the roller brake tester is off. Do not use the brake tester to start vehicle. tangement, crushing	<i>Fit roller covers when not in use, do not turn rollers on when a vehicle is placed on rollers, wait for rollers to complete their cycle and do not interrupt cycle.</i>	
	1.		

PURPOSE/PROCESS

Testing of vehicle brakes.

PROCEDURES:

DO NOT use this machine unless you have proven to your trainer that you are competent in its safe use and operation

Pre Start Check

1. Check that the operating area is uncluttered and no loose items are lying around.
2. Remove roller covers and store safely.
3. Turn on rollers and let warm up – rollers will perform a self-check..

Operation

1. Turn on rollers and set for 2 wheel drive or 4 wheel drive (rollers go through a set up phase).
2. Remove covers.

3. Advise staff and students of commencing brake test.
4. Drive on evenly with foot off brake rollers will do a self-test until orange light comes on (top right).
5. Now set for brake test.
6. When green lights come on you can drive forward to do rear brakes (hand brake).

Close Down

1. When green lights come on you can drive off rollers.
2. Refit covers, turn off machine.

Routine maintenance

Lock out and/or isolate any equipment before inspection or maintenance

	Name	Title/Position	Signature	Date
Author	George Fisher	Technician		17/08/20
Reviewed by	Marie Denis	HSW Manager		
Reviewed by	Tony Middlemiss	Health and safety rep		
Manager	Joe Nathan			

Document Control

Date	Revision number	Modifications	Revised by	Approved by
17/08/20	1	New format	George Fisher	Marie D